Sealants & Adhesives



Supply Systems



Supply System Platform





Product Position



THE NEXT GENERATION

What that means is:

- Leading Quality
 - Lowest Cost of Ownership
 - Easy to Use
 - Easy to Maintain
- Unbeatable Service
 - Fast Delivery
 - Flexible Product Offering
 - Easy Ordering
- Technology Differentiation
- Modular components for flexibility & reliability



Quality



Seal life

2-3x the competition

NXT air motor

40 million cycle MTBF (4x the King)



CYCLES

Graco Severe

	Duty	Graco MaxLife	SCA	Aro
Foot valve	80000	80000	12100	4300
Throat seal	40000	110000	*	*
Priming piston	25000	80000	*	5600

^{*} Foot valves failed so frequently it wasn't possible to test other seals to failure

⁻ Test conducted with Sherwin Williams A100 paint (used for it's abrasive attributes)

Performance



- Fastest changeover in the industry
- Noise Level
- 87dB @ 100psi
- Closest competition is 90dB
- Large range of pump and ram options to meet all viscosity, flow rate, and pressure demands





Ease of Use & Serviceability



- Easy drum removal with one-button blow-off
- Integrated air controls locate all controls in one location
- All three NXT air motors share common wear components
- Throat seals can be serviced without removing pump from ram
- Wiper seals can be easily removed and replaced
- Pump, air motor, and platen can be serviced individually without removing other components



Upgrade options



DataTrak

- Runaway control & pump diagnostics
- Material totalizers & maintenance counters
- Optional low/empty sensor & light tower



- Everything included with DataTrak, plus . . .
- Automatic crossover, including due to runaway
- Optional depressurization/recirculation & filter pressure monitoring

MaxLife

- For abrasive materials & long-life
- MaxLife coating on rods & cylinders
- Unique MaxLife seals
- Enclosed wetcup





Ease of Use Accessories



- Drum Roller 255627
 - Allows easy loading of 55g drums
- Platen Cover 255691
 - Protects top of platen from filling with material



- Enclosed Wetcup Recirculation Kit 255703
 - Provides recirculation of TSL between an enclosed wetcup(s) and a 5g pail
- Fluid Purge Kit 255690
 - Allows the pump to purge/prime into a 5g pail

